


ASSEMBLY INSTRUCTION

JOLINA ARMCHAIR









Legs must be retightened regularly or when needed