






ASSEMBLY INSTRUCTIONS FOR CHENNAI WHITE DINING TABLE
(SKU#1523341-01-0/1523342-01-0)


<p>Fig. 1</p>  <p>Leg : 1 Pc</p>	<p>Fig. 2</p>  <p>Table Top : 1 Pc</p>	 <p>Bolts:4+2 pcs Washer :4+2 Pcs</p>	 <p>Allen key : 1 Pcs</p>
---	--	--	--

Pre-assembly:

- Please read all instructions carefully before beginning assembling.
- It is recommended that assembly is done on a soft surface such as carpet to avoid any damage.
- We recommend adult assembly by two people for your safety.



- Step 1 : Turn table top upside down onto a clean surface as shown in the Fig. 2.
- Step 2 : Match label on table top with the label on leg ("A" with "A" and "B" with "B") as shown Fig. 3.
- Step 3 : Put the washer on to a bolt and Insert into the leg & tighten with the allen key provided (Fig. 4).
- Step 4 : Repeat this for remaining holes on the leg.
- Step 5 : Turn the table in upright position after assembly as shown in Fig 6.



Care Information:

- Clean using a soft, dry cloth.
- Do not use harsh abrasives, chemicals or polishes containing silicone to as they can damage this finish.
- Avoid direct sunlight as this will cause the timber to change colour.
- It is important to remove moist substances immediately.