



Jotex

1552148-01/1552148-02/1552148-03/1552148-04
1552148-05/1552148-06





Assembly Instruction



15MIN

1



Ax10



Bx1



Cx10



2


Ax6



Bx1



Cx6



3



Ax4



Bx1



Cx4



adjust the adjustable leg to the same level