

ASSEMBLY INSTRUCTION




Ax1



Bx4





A