






## ASSEMBLY INSTRUCTION

**ITEM NAME : WALL DISPLAY, NATURAL, MANGO**






**Item No. : 82048127**



## Components List

Item	Description	Quantity
A	Main Frame- Large 	2 Pcs
B	Main Frame- Small 	2 Pcs
C	Cabinet 	1 Pc
D	Shelf-Small 	2 Pcs
E	Shelf-Large 	1 Pc

## Hardware List (Included)

Item	Description	Quantity
A	Screw (0.25"X2.75") and Anchor  	10 Pcs each
B	Wood Plug 	10 Pcs
C	Screws for main frame (0.25"X0.5") 	24 Pcs
	Clamping Clip 	12 Pcs

# ASSEMBLY STEPS

**Step 1:** Place the main frame, large and small, on floor, as per image below:



**Step 2:** Insert shelves and cabinet at desired height.



**Step 3:** Gently invert the entire piece and screw clamp with the help of two screws for main frame.



**Step 4:** Raise the entire fixture & place it against a wall. Identify & mark location of 10 holes to drill screws. Drill holes on these marked locations & gently hammer the anchors. Place the fixture back & tighten all 10 screws.



**Step 5:** Gently insert wood plugs in these holes to cover the screws.



**Max recommended weights :**

**Small shelves      22 lbs**

**Cabinet              22 lbs**

**Large shelf   40 lbs**

**Caution :**

**Do not stand on this fixture.**

**Do not place weights with force.**

