

PENNY

Shelf






TOOLS




HARDWARE



PARTS





IN ORDER TO MAINTAIN THE PRODUCT FROM DIRT OR MARKS, USE A CLOTH WITH MILD SOAP AND WATER. DRY WITH A SOFT CLOTH. THIS IS THE ONLY METHOD OF GUARANTEEING THAT THE ORIGINAL APPEARANCE IS MAINTAINED. OTHER COMMERCIALLY AVAILABLE CLEANING AGENTS SHOULD NOT BE USED.