



# LEVEL


## Sofa Table



## TOOLS




## HARDWARE




A x 16


## PARTS



① x1



② x1




③ x2


1



LOOSE ATTACHMENT




2




3


TURN 180°



4



TIGHTEN SCREWS



# CARE INSTRUCTIONS

In order to maintain the product from dirt or marks, use a cloth with mild soap and water. Dry with a soft cloth. This is the only method of guaranteeing that the original appearance is maintained. Other commercially available cleaning agents should not be used.

