



NINA


Dining Table



TOOLS




HARDWARE




A x 24


PARTS



① x1




② x4




③ x1


1






2



3



4



CARE INSTRUCTIONS

In order to maintain the product from dirt or marks, use a cloth with mild soap and water. Dry with a soft cloth. This is the only method of guaranteeing that the original appearance is maintained. Other commercially available cleaning agents should not be used.

