




3

DORA LADA TV 140

KURULUM ŐEMASI

ASSEMBLY GUIDE

