


2168957






GINGERHOUSE LEDTable lamp Manual

PLEASE READ THESE INSTRUCTIONS CAREFULLY BEFORE COMMENCING
ASSEMBLY AND RETAIN FOR FUTURE REFERENCE.



FRONT

BOTTOM



ASSEMBLY INSTRUCTIONS:

1. Open the battery cover on the bottom, push the plastic sheet.
2. Insert 3xLR44 1.5 V batteries into the battery compartment. Note the polarity of the batteries.
3. Close the battery cover. Note the mounting position
4. Turn the ON/OFF/Timer switch of the battery compartment to the position.

CAUTION:

- .Not suitable for children!
- .Use for the intended purpose only.
- .Only use inside, only use in dry environment.Avoid direct eye contact with the LED.
- .Do not use if the product is damaged.
- .The installed LEDs are not interchangeable.



FR
Cet appareil
se recycle



À DÉPOSER
EN MAGASIN À DÉPOSER
EN DÉCHÈTERIE

Points de collecte sur www.quefai-redemesdechets.fr
Privilégiez la réparation ou le don de votre appareil !

