


SHIRO PENDANT

T476002

T488002

Assembly instructions

WATT&VEKE®



1. Stäng av strömmen
2. Tryck på lampskärmen för att separera den från träringen
3. Sätt in ljuskällan
4. Fäst lampskärmen på träringen
5. Justera sladden till önskad längd
6. Fäst kroken i taket och häng upp pendellampan
7. Anslut ledningen
8. Montera takkoppen
9. Dra åt skruven
10. Slå på strömmen

Nätanslutning: 220-240V~ 50Hz.

Ljuskälla: E27 Max 10W LED

Ljuskälla säljs separat

Endast för inomhusbruk


Om den yttre böjliga kabeln eller sladden till denna belysning skadas, får den endast bytas ut av tillverkaren eller dennes serviceagent eller annan behörig person för att undvika eventuella risker.

Skötselråd

Rengör med en torr, mjuk trasa. Använd en fuktad trasa med en mild rengörande produkt vid behov. Använd ej slipande eller starka rengöringsmedel.



Symbolen med den överkorsade soptunnan anger att produkten inte får hanteras som hushållsavfall. Produkten ska lämnas in för återvinning i enlighet med lokala miljöbestämmelser för avfallshantering. Genom att återvinna produkten hjälper du till att minimera potentiella negativa effekter på människors hälsa och på miljön.



1. Turn off the power
2. Press the lampshade to separate it from the wooden ring
3. Insert the light source
4. Fix the lampshade to the wooden ring
5. Adjust the cable length to the length you want
6. Fix the hook to the ceiling and hang up the pendant lamp
7. Connect the wire
8. Fix the canopy
9. Tighten the screw
10. Turn on the power

Rated voltage: 220-240V~ 50Hz.

Light source: E27 Max 10W LED

Light source is sold separately

For indoor use only

If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.

Cleaning instructions

Wipe off dust with dry soft cloth. Remove stains with water and a light detergent or soap applied with a damp cloth. Do not use detergents containing abrasives or solvents.



The crossed-out wheeled bin symbol indicates that this product may not be treated as household waste. It should be disposed of in accordance with local environmental regulations for waste disposal. By recycling this product, you will help to minimize potential negative consequences for human health and the environment.

**THANK YOU
FOR CHOOSING
A WATT&VEKE
LIGHTING PRODUCT**

Watt&Veke AB | Tegnérgatan 14 | S-113 58 Stockholm, Sweden

wattveke.se