ASSEMBLY INSTRUCTIONS

Hanger Lord - Gold - No Size

1586987-01-0



COMPONENTS & HARDWARE			
A		Coat Hanger	1 Pc
B		Utility Tray	1 Pc
C		Trouser Hanger	1 Pc
D		Base Pole	1 Pc
E		Base	1 Pc

Step-1: Tightly Screw the Base Pole (D) with the Base (E)



Step-2: Place the Trouser Hanger (C) over the Base Pole (D) and Screw tightly with the Knob



Step-3: Place the Utility Tray (B) over the Base Pole (D) and Screw tightly with the knob



Step-4: Tightly Screw the Coat Hanger (A) on the top of Base Pole (D)



Note - At the time of assembly, the trouser Hanger and the Pocket change Dish is slid from the top. The wing nut at the back is used to tighten and fix the hardware at the desired location. At the time of assembly, the poles may gather scratches, handle carefully.