ASSEMBLY INSTRUCTION



Ax1

Bx4





A